

## Touring Trunk Installation Instructions



The LED Lighted (optional flashing) Rear Spoiler in black is injection molded ABS plastic. The Spoiler can be wired as a brake light or running light, but not both at the same time. The flashing option is built into the spoiler, you can choose either solid brake lights or flashing brake lights (depends on the wiring).

### **Installation Procedure for H-D Tour-pak or our After-market Touring Trunk:**

Green/Yellow Wire: .....12V (+) solid brake lights  
Brown: .....12 V (+) optional flashing brake lights  
Green: .....ground (-)

- 1) For our After-market Touring Trunk: Drill 4 (size 11/64) holes on the top lid of the trunk (circle marks for drilling can be found underneath the trunk lid).

For H-D tour-pak: Align and locate the LED Spoiler on the back of the tour-pak lid and temporarily secure with masking tape. Position pieces of masking tape on the tour-pak at the top and side edges of the LED Spoiler mounts to mark the mount locations. Remove the LED Spoiler. Locate the drilling templates at the mount locations marked by the masking tape. Drill the 4 (size 11/64) holes on the top lid of the tour-pak.

- 2) On the left side, near the tour-pak hinge, drill another (size 5/16) hole between the two mount holes. This is for the electrical wires to go through.
- 3) Place the plastic washers between the LED Spoiler and the tour-pak lid. Secure from underneath with provided 4 screws.
- 4) Splice the LED Spoiler wires to the running or brake lights.

Harley-Davidson and Tour-Pak are registered trademarks of Harley-Davidson, Inc. eGlideGoodies has no affiliation with Harley-Davidson, Inc. The use of these terms is for identification purposes only.