

# eGlideGoodies

*Functional Products for Harley-Davidson Electra Glides*

## Lockable Sealed Glove Box Doors (Model GD-2) for Road Glide Installation Instructions

Congratulations on the purchase of your Lockable GD-2 Sealed Glove Box Doors. This product will give you more storage options and added convenience on your Road Glide equipped with lower fairing glove boxes. The installation is straightforward and easy. If you have any questions, email [support@eglidegoodies.com](mailto:support@eglidegoodies.com).

**Inventory:** The kit includes the following:

1.
  - A. right and left lockable door/frame assembly (2)
  - B. allen machine screws, washers, lock washers and nuts (8 each)
  - C. barrel key (2)
  - D. allen wrench (1)
  - E. Installation instructions



### **Caution:**

Make sure to wear proper eye protection during the installation!

### **Glove Box Snap Removal:**

2. Remove the stock right side snap-on glove box door and remove the security tether by cutting the tether.
3. On the glove box, determine if the snaps are plastic push-ins or metal snaps. If metal, to assist in the drilling process (so the snaps do not rotate with the drill bit) deform to flatten the sides of each snap a bit. If the snaps are metal grab each snap with pliers prior to drillings.
4. Using an 11/64" or 3/16" drill bit, drill out each of the four replaceable plastic snaps (or metal snaps) from the glove box by positioning the drill bit in the center of each snap. (This will be very easy and the snaps can be replaced later if needed.)

5. For metal snaps, once the snap is removed, you can squeeze each retaining pin to make smaller so they can be removed from the inside of the glove box. Or snip the top off with a pair of snips.
6. Discard the plastic ring that can now be removed.

**Lockable Glove Box Door Installation:**

7. Unlock and open the right lockable door assembly (right door is straight on the left side, slanted on the right side) and position it on the glove box in the door opening and align the four holes.
8. If the snap was metal you may need to widen each of the glove box holes. Using one of the door frame holes as a guide, drill through this hole to widen. Put one screw and nut in this hole and snug up lightly.
9. If needed repeat this procedure for the remaining three holes. Temporarily remove the GD-2 assembly.
10. Clean out any plastic shavings form the inside of the glove box.
11. Re-install the GD-2 door assembly. Insert 4 machine screws. Inside the glove box, attach a washer, lock washer and nut for each screw. Tighten each nut securely.
12. Check free movement of the sealed glove box door. For GD-2 insert a key and check the locked and unlocked positions.

**Notes:**

- To Unlock or Open: Insert the key then push the key slightly as you turn the key to unlock. The key will stay in the lock when the lock is in the unlocked position to provide a handle.
- To Lock or Close: Close the door then push the key slightly as you turn the key to lock. Remove the key.
- If the doors close too tightly or not tightly enough, you can fine tune this by adding or removing washers to shim the cam in or out or by making small adjustments in the bend of the lock

latch cam (arm) at the back of the door or. Your latch arms have been set at the factory with 2 shim washers.

- The GD-2 kit includes two identical keys.

13. Repeat steps 2 through 4 for the left glove box.



**Caution!**

You should not ride the motorcycle while opening, using or closing the glove box with sealed doors! You should safely pull off the road and come to a complete stop at a location away from moving traffic prior to use.

We welcome your feedback! Please email your comments about this product or installation to [support@eglidegoodies.com](mailto:support@eglidegoodies.com).

Harley-Davidson, Road Glide are registered trademarks of Harley-Davidson, Inc. eGlideGoodies has no affiliation with Harley-Davidson, Inc. The use of these terms is for identification purposes only.